

Troubleshooting Devices


Troubleshooting the Worth Data Cordless Laser Scanner

The default settings for a Worth Data Cordless Laser bar code scanner may not allow the scanner to read bar codes on receipts generated by a thermal printer. To adjust the settings for this product, use the following series of bar code commands, provided by Worth Data on their Wireless Setup Menu.


1. Start Setup



2. Setting Option Code #1



3. Setting Option Code #2



4. Complete Setup



For more information about troubleshooting Worth Data cordless bar code scanners, contact Worth Data. For information on troubleshooting other bar code scanners, contact the manufacturer.